

IP 7505 E-Change Film

Installation Recommendations and Post-Installation Care

Pre-Installation Recommendations

- Before installation, the glass surface should be completely clean
- All traces of dust, dirt and/or grease must be completely removed
- The use of an anti-static spray is beneficial
- A compatibility test should be carried out before installation to avoid blisters in the film
- The film should always be kept flat and straight; it should never be bent or curled

Installation Recommendations

- The film must be applied dry as wet application will permanently damage it
- Keep the top liner in place until installation is complete
- Wear anti-static gloves throughout the installation process in order to avoid the transfer of dust, dirt and/or grease
- Wear anti-static overalls throughout the installation process to reduce the possibility of attracting dust
- In the event of a join being needed, a gap should be left between the panels of between 0.5mm and 1.0mm (to prevent an electrical short circuit from damaging the film)
- The film should not be subject to pressure and so must not be installed under the frame of the window

Post-Installation Recommendations

- Do not clean the E-Change Film for at least 1 month after application
- Do not use abrasive cleaning products, including ammonia, brushes and scrapers as these are likely to damage the surface of the film
- Instead, use a soft, microfiber cloth
- Do not apply any type of sticker or adhesive on the film

